



Sheet Drain Installation Guideline

3904 Virginia Ave • Cincinnati, Ohio 45227 • Phone (513) 271-6000 • Fax (513) 271-4420

INSTALLATION PROCEDURES

DESCRIPTION

Prefabricated drainage composite designed to enhance waterproofing / damproofing membrane by quickly channeling water down to the collection pipe and protecting the membrane during backfilling.

NOTE

Rolls can be installed horizontally or vertically along the footer. When installing horizontally, begin at the bottom of the wall or foundation.

- 1) Place the 1st course of Drain Board with the fabric facing the soil, dimples pointed away from the wall.
- 2) Fold the bottom edge of the fabric and tuck behind the core, keeping soils out of the core.
- 3) Attach the Drain Board panel either with mechanical fasteners or adhesives to hold in-place until backfilled. Check with the waterproofing manufacturer for approved adhesives compatible with their membrane or recommended methods.
- 4) 2nd course is placed with the core butted to the lower course overlapping the fabric using the shingle method. Secure fabric with duct tape.
- 5) The top course should be terminated by tucking the fabric flap over the top of the core.
- 6) Backfill should be placed immediately and cover at least 6 inches above the top course of Drain Board.

It is recommended that you consult with your waterproofing membrane contractor and/or manufacturer to obtain installation guidelines pertaining to their products.