



**NOTES:**

- 1.) Stretcher frame can be made from 2x4 wood, steel or aluminium tubing
- 2.) Pins will be 1/2" Dia. spikes or 1/2" threaded rod
- 3.) Place stretcher frame over section in place.
- 4.) Fill cell section, then remove frame.

ENVIROGRID provides this information only as an accommodation to our customers. No warranty or other representation regarding the suitability of the above application procedure is made due to the fact that each installation has specific requirements that may not have been considered in this generalized procedure. ENVIROGRID makes no warranties or representations regarding the suitability of its ENVIROGRID products for specific uses or applications. Our liability is limited to furnishing, without charge, a replacement for any ENVIROGRID section that is proven defective under normal use or service.

**ENVIROGRID™**

By TKP	EGA-30 - Stretcher Frame	Rev # 0
Scale: None	Date: 09-18-03	Drawing No. EmsStd-019